
SECTION 32

POWER PLANT MOUNT

CONTENTS

General.....1 Transmission Mount.....2

General

The servicing information specified below accompanies transmission changes to the newly installed 6-speed manual transmission. Other servicing information remains the same.

Transmission Mount


Removal and fitting

CAUTION

* Indicates parts which should be initially tightened, and then fully tightened when the engine weight is supported by the vehicle body.

Jobs to do before removal and after fitting


- Removal and fitting of cover (ref. Chapter 51 – Front Bumper)
- Removal and fitting of battery and battery tray
- Removal and fitting of air cleaner ASSY
- Removal and fitting of air pipe C, air by-pass hose, and air hose D (ref. Chapter 15 – Intercooler)
- Removal and fitting of radiator
- Jack up the engine and transmission ASSY to a position where there is no weight on the insulator (before removal)
- Removal and fitting of rear roll stopper



Removal Procedure

1. Transmission mount coupling bolt
2. Transmission mount

▶ A ◀ 3. Transmission mount stopper



Fitting

▶ A ◀ **Fitting transmission mount stopper**

Fit so that the arrow on the transmission mount stopper is vertical relative to the vehicle body.