

SECTION 52A

INTERIOR


CONTENTS

General1 Interior mirror1
 Boot interior trim1

General

- The removal information for the boot interior trim has been changed due to the addition of a front trim.
- The removal information for the interior mirror has been changed due to design changes in the mirror.

Boot interior trim




Remarks

← This symbol indicates the position of the clip

AAC211106

- 1. Rear end trim
- 2. Side trim lid

- 3. Side trim
- 4. Front trim



Interior Mirror

Removal procedure

1. Detach fitting at holder A, and pull cover down in direction of arrow 1.
2. Press holder B in direction of arrow 2 to disengage lock, and then pull mirror down in direction of arrow 3.