



7501 Straw Plains Pike, Knoxville, TN 37924

Tech Support: (760) 244-2049

Ford 1992-1996 E Series Van 4.9 & 7.5L
Ford 1992 E Series Van 5 & 5.8L
Ford 1995-1997 F Series Pickup 7.5L
Ford 1995-1998 Windstar 3L
Mercury 1987-1993 Cougar 3.8L WO/Supercharger

Supplied Items:

Large Case Conversion Alternator with attached Bracket

Installation Instructions:

- 1 Disconnect the negative battery cable and then disconnect the positive battery cable.
- 2 Disconnect the wiring, remove the belt, and then remove the stock alternator from its mounting brackets.
- 3 This is a direct mount alternator so it will be installed on the existing mounts that the stock alternator was. Tighten all the bolts sufficiently enough to ensure that the belt has the correct tension.
- 5 Connect the stock alternator plug directly into the newly installed alternator Plug.
- 6 Connect two new cables(1/0 awg.)**(not supplied)** between the alternator Post and the battery post, connecting the positive cable first and the negative post last. The original cables will not be used and therefore be individually covered with electrical tape and/or heat shrink tubing to prevent the cables from shorting against each other.