

Instructions

2006 Service Manual

When you print this manual, it should be separated into several volumes. In addition to this, please note the followings:

- The "Hydraulic Circuit" section on Group 23A should be color-printed. For 4AT, the color identifications are the same as the 2005 PS41 manual. For 5AT, the color identifications are as attached.
- Each volume should have "Foreword" pages at its beginning. **In addition, you should add "tab" on the right end of the first page of each group. The tab should be aligned with the appropriate "Foreword" page.**
- Each volume should have "Alphabetical Index" pages at its end. The "Alphabetical Index" are the same for all volumes.

2006 PS24S (MMNA) Service Manual

GROUP NO.	GROUP NAME	PAGE
-	FOREWORD <Vol. 1>	4
00 (TOC)	(GENERAL)	2
00	GENERAL	70
00E	GENERAL ELECTRICAL	16
11 (TOC)	(ENGINE)	2
11A	ENGINE MECHANICAL <2.4L ENGINE>	66
11B	ENGINE OVERHAUL <2.4L ENGINE>	72
11C	ENGINE MECHANICAL <3.8L ENGINE>	68
11D	ENGINE OVERHAUL <3.8L ENGINE>	72
12	ENGINE LUBRICATION	8
13 (TOC)	(FUEL)	2
13A	MFI <2.4L ENGINE>	1218
-	INDEX	11
-	FOREWORD <Vol. 2>	4
13B	MFI <3.8L ENGINE>	1300
13C	FUEL SUPPLY	16
14	ENGINE COOLING	44
15	INTAKE AND EXHAUST	28
16	ENGINE ELECTRICAL	54
17	ENGINE AND EMISSION CONTROL	112
21 (TOC)	(CLUTCH)	2
21A	CLUTCH	20
21B	CLUTCH OVERHAUL <F5M42>	8
21C	CLUTCH OVERHAUL <F6MBA>	6
22 (TOC)	(MANUAL TRANSAXLE)	2
22A	MANUAL TRANSAXLE	24
22B	MANUAL TRANSAXLE OVERHAUL <F5M42>	54
22C	MANUAL TRANSAXLE OVERHAUL <F6MBA>	62
23 (TOC)	(AUTOMATIC TRANSAXLE)	2
23A	AUTOMATIC TRANSAXLE	424
23B	AUTOMATIC TRANSAXLE OVERHAUL <F4A4B>	76
23C	AUTOMATIC TRANSAXLE OVERHAUL <F5A5A>	86
26	FRONT AXLE	34
27	REAR AXLE	10
31	WHEEL AND TIRE	8
32	POWER PLANT MOUNT	18
33	FRONT SUSPENSION	28
34	REAR SUSPENSION	28
35 (TOC)	(SERVICE BRAKES)	2
35A	BASIC BRAKE SYSTEM	42
35B	ANTI-LOCK BRAKING SYSTEM (ABS)	148
-	INDEX	11
-	FOREWORD <Vol. 3>	4
35C	TRACTION CONTROL SYSTEM (TCL)	164
36	PARKING BRAKES	22
37	POWER STEERING	68
42	BODY	108
51	EXTERIOR	48
52 (TOC)	[INTERIOR AND SUPPLEMENTAL RESTRAINT SYSTEM (SRS)]	2
52A	INTERIOR	54
52B	SRS	454
54 (TOC)	(CHASSIS ELECTRICAL)	2
54A	CHASSIS ELECTRICAL	266
54B	SIMPLIFIED WIRING SYSTEM (SWS)	552
54C	CONTROLLER AREA NETWORK (CAN)	142
55 (TOC)	(HEATER, AIR CONDITIONING AND VENTILATION)	2
55A	HEATER, AIR CONDITIONING AND VENTILATION	218
55B	AUTOMATIC AIR CONDITIONING	192
70	COMPONENT LOCATIONS	22
80 (TOC)	(CONFIGURATION DIAGRAMS)	2
80A	CONFIGURATION DIAGRAMS	24
80B	SPLICE LOCATIONS	8
90	CIRCUIT DIAGRAMS	416
-	INDEX	11
TOTAL		7045

1611

2651

2781